


# Assembly instructions for the 10-000-011 Kit


## REMOVING THE PLASTIC FASTENERS

Remove the plastic fasteners attaching the circuit board and LCD module. Make sure that the plastic standoffs remain under the mounting tabs.




## INSERTING NEW FASTENERS

Please use the 4-40 x 3/8" Philip head screws supplied with the kit. Insert the screws into the mounting tabs (where plastic fasteners were previously).



## PREPARATION FOR MOUNTING

Please use the template included with this documentation for the cut-out on the panel. You have an option to mount the LCD module directly to the plate before or after mounting to the panel. When mounting the LCD module make sure that it is positioned in the center of the plate.




## FINIAL STEP

Make sure the mounting area on the panel is clean and remove the adhesive tape backing on the plate. Use the M3 nuts supplied to secure the plate to the panel. Do not over tighten the nuts.




## PAINTING

Before painting the plate masked the rubber seal to prevent it from being coated.



# Assembly instructions for the 10-000-011 Kit



MeerKat Systems, Inc.  
 PO Box 2074  
 Crystal Lake, IL 60039-2074